REVIEW DATE NAME OF FOREIGN LABORATORY U.S. DEPARTMENT OF AGRICULTURE FOOD SAFETY AND INSPECTION SERVICE INTERNATIONAL PROGRAMS 5/16/2000 Laboratory of the Government Chemist FOREIGN COUNTRY LABORATORY REVIEW ADDRESS OF LABORATORY CITY & COUNTRY **FOREIGN GOV'T AGENCY** London, England Queens Road, Taddington, Middlesex See Reverse NAME OF REVIEWER NAME OF FOREIGN OFFICIAL Mr. Reg Perry, Mr. Ian Lumley, Dr. Colin Penny Dr. Gary D. Bolstad

	Dr. Gary D. Boistad Wir. Reg Perry, Wir. Iair Daintey, Dr. Colin Penry														
Residue Code/Name			>	100	200	300	400	500	600	800	900	Lev	Cbd	Ivm	
SAMPLING PROCEDURES	REVIEW ITEMS Sample Handling	ITEM #		A	A	A	A	A	A	A	A	A	A	A	
	Sampling Frequency	02	03 COD EVALUATION COD	A	A	A	A	A	A	A	A	A	A	A	
	Timely Analyses	03		С	С	С	С	С	С	С	С	С	С	С	
	Compositing Procedure	04		o	o	o	0	o	o	o	o	o	0	0	
	Interpret Comp Data	05		o	o	o	0	o	o	O	o	О	0	0	
	Data Reporting	06		A	A	A	A	A	A	A	A	A	A	A	
ANALYTICAL PROCEDURES	Acceptable Method	07	CODE	A	A	A	A	A	A	A	A	ıc	LC?	ıc	
	Correct Tissue(s)	08		A	A	A	A	A	A	A	A	Liv	?	Liv	
	Equipment Operation	09	EVALUATION	A	A	A	A	A	A	A	A	A	A	A	
	Instrument Printouts	10	E	A	A	A	A	A	A	A	A	A	A	A	
QUALITY ASSURANCE PROCEDURES	Minimum Detection Levels	11	12	A	A	A	A	A	A	A	A	A	A	A	
	Recovery Frequency	12		A	A	A	A	A	A	A	A	A	A	A	
	Percent Recovery	13	CODE	A	A	A	A	A	A	A	A	A	A	A	
	Check Sample Frequency	14	EVALUATION	С	С	С	С	С	С	С	С	С	С	_c _	<u> </u>
	All analyst w/Check Samples	15	ALU,	С	С	С	С	С	С	С	С	С	С	С	
	Corrective Actions	16	6	A	A	A	A	A	A	A	A	A	A	A	
	International Check Samples	17		0	0	0	0	0	0	o	o	0	0	0	
REVIEW PROCEDURES	Corrected Prior Deficiencies	18	EVAL. CODE	o	o	o	o	o	o	0	o	o	o	o	
OTHER REVIEW		19	CODE												
		20	EVAL.												

				7° VE-	111110 40						
FOR	IGN COL	JNTRY LABORATOR	Y REVIEW	REVIEW DATE	NAME OF FOREIGN LABORATORY						
	((Comment Sheet)		5/16/2000	Laboratory of the Government Chemist						
FOREIGN GO	OV'T AGEN	CY	CITY & COUNTRY	1	ADDRESS OF LABORATORY						
	See Rev	erse	London,	England	Queens Road, Taddington, Middlesex						
	NAME OF REVIEWER Dr. Gary D. Bolstad			NAME OF FOREIGN OFFICIAL Mr. Reg Perry, Mr. Ian Lumley, Dr. Colin Penny							
RESIDUE	ITEM			COMM	IENTS						
All	03	analysis, for all class days. Note: field san	receipt of samples in the laboratory and completion of days. FSIS expects a turnaround time of 10 working were processed immediately upon receipt.								
	08	The following were used as matrices for these determinations: CHCs - fat for meat samples and liver for poultry samples; antibiotics - kidney; hormones - urine and bile; nitrogen pesticides - kidney fat for meat and liver for poultry; and liver for levamisole and ivermectin.									
All	14-15	There was no intra-laboratory check sample program. Analyst proficiency in this laboratory was evaluated via participation in a Food Analysis Performance Assessment Scheme (FAPAS), an inter-laboratory check sample program used within the European Community. Under this program, a set of check samples for each of the residue categories was provided every 2 or 3 months, and each section in the laboratory (but not necessarily each analyst within each section) participated in the analysis of these check samples. Note: FSIS expects each analyst, who participates in field sample determinations for the national residue testing program for meat and poultry, to participate in a monthly intralaboratory check sample program for each class of compounds for which that analyst performs the analyses for the field samples.									
		NOTE: In spite of the official name of the laboratory, it was not owned or operated by the government agencia involved with meat inspection, but was rather privately-owned. One-third of the shares of the company were owned by each of three groups: (1) the management and staff of the laboratory, (2) the Royal Society of Chemistry, which also audited the laboratory annually to ensure that standards were being maintained "on a lever that would be expected if the laboratory, were still government-owned," and (3) a private group of investors in technology ventures.									



United States
Department of
Agriculture

Food Safety And Inspection Service Technical Service Center

Suite 300, Landmark Center 1299 Farnam Street Omaha, NE 68102

Microbiology Laboratory Audit

General

Name & location of lab: Allied Laboratory Services Ltd., Grimsby, England, 5/15/00

Private or gov't lab? Private

How & when was accreditation obtained? MAFF has not officially issued accreditation to this lab, but has assessed the laboratory for compliance with the national laboratory standard, has determined that it meets the requirements, and has officially notified Malton Bacon Factory that the microbiological testing for compliance with USDA requirements may be satisfied with this laboratory.

How & how often is accreditation maintained? See above.

When and how is payment for analysis provided? *Malton Bacon Factory (Est. 2060)* is billed at the end of each month for the services provided during that month.

Are results released before payment is received? Yes.

What are the qualifications of the analyst(s) performing the individual tasks within a method? All have participated in an internal training program, within the laboratory, for at least three years.

What are the qualifications of the direct supervisor of the analyst(s)? BSc in applied biology

Methodology for HACCP Salmonella samples (regulatory labs)

Does this lab analyze HACCP Salmonella samples? Yes

How are HACCP Salmonella samples received & recorded? A refrigerated vehicle belonging to the laboratory picks them up at the Est. 2060.

Are HACCP Salmonella samples analyzed on the day of receipt? Yes

What method(s) is used for HACCP Salmonella samples? The British Standard Method, EN 12824, published by the European Committee for Standardization (CEN). This method was supplied to FSIS International Policy Division in 1998. According to laboratory officials, it has been determined to be equivalent to the AOAC method.

Is it a qualitative method (i.e. +/- result)? Yes.

Are HACCP ground beef samples analyzed for Salmonella? No

What is the size of the ground beef test portion? N/A

What buffer (and what volume) is used for:

Sponge samples for Salmonella? The buffer solution is obtained and used by Est. 2060. This laboratory supplies the sponge and Whirl-Pak.

Poultry rinsates for Salmonella? N/A

Salmonella ground beef sample homogenates? N/A

What is the formulation of the Buffered Peptone Water you use? Will obtain from Est. 2060

What analytical controls are used for *Salmonella* analyses (i.e. control cultures, etc.)? Both positive and negative controls.

Are they employed for each sample set? Yes

How are HACCP Salmonella results expressed? "Present" or "Not Detected"

How are HACCP Salmonella results recorded:

Data sheets/work sheets? Raw data are recorded on work sheets. Results are then stored in a computer progam. A printed report is sent by mail to the veterinarian in charge (Official Veterinary Surgeon) in Est. 2060.

and/or Log books? No-see above.

How and to whom are HACCP Salmonella results reported? See above.

Are "check" samples periodically used to test the proficiency of the lab and analysts for Salmonella testing? Yes. The laboratory participates in an external quality assurance program.

- 1. For individual analysts or for the lab as a whole? Both.
- 2. What species/strains are used? The internal samples are done with <u>Salmonella poona</u>. The strains used in the external samples vary, and include <u>S. anatum</u>, <u>typhimurium</u>, <u>indiana</u>, and <u>enteritidis</u>.
- 3. How many samples are analyzed and how often? *Internally with each set of field samples*.
- 4. Are both inoculated and uninoculated samples provided to analysts for the proficiency testing? Yes
- 5. How many colony-forming units (cfu) per gram are inoculated into the proficiency samples provided to analysts? 1-10 (<u>S. anatum</u> and <u>indiana</u>) and 10-100 (<u>S. typhimurium</u> and <u>enteritidis</u>).

Methodology for HACCP generic E. coli samples (in-plant or other private labs)

Does this lab analyze HACCP generic E. coli samples? Yes

How are HACCP E. coli samples received & recorded? Same as above

Are HACCP E. coli samples analyzed on the day of receipt? Yes

What method is used for HACCP generic *E. coli* samples? *British Standard*5763-13:1998. This method was supplied to FSIS International Policy Division in 1998. It has been determined to be equivalent to the AOAC method.

Is it a quantitative method? Yes

What buffer (and what volume) is used for:

E. coli sponge samples? The buffer solution is obtained and used by Est. 2060. This laboratory supplies the sponge and Whirl-Pak.

Poultry rinsates for generic E. coli? N/A

What analytical controls are used (i.e. control cultures, etc.)? Both positive and negative controls.

Are they employed for each sample set? Yes

How are HACCP E. coli results calculated and/or expressed? Number of CFUs /cm²

How are E. coli results recorded:

Data sheets/work sheets? Raw data on work sheets. Results are then stored in a computer progam. A printed report is sent by mail to the veterinarian in charge (Official Veterinary Surgeon) in Est. 2060.

Log books? No—see above.

How and to whom are HACCP E. coli results reported? See above.

Are "check" samples periodically used to test the proficiency of the lab and analysts for generic *E. coli* testing? Yes

- 6. For individual analysts or for the lab as a whole? Both.
- 7. What species/strains are used? E. coli (not more narrowly defined)
- 8. How many samples are analyzed and how often? *Approximately 18 per year.*
- 9. Are both inoculated and uninoculated samples provided to analysts for the proficiency testing? Yes
- 10. How many colony-forming units (cfu) per gram are inoculated into the proficiency samples provided to analysts? *Examples:* 10³, 10⁴, 10⁶