



Foreign Material Detection and Control

FSIS Meeting

Omaha, NE

Sept. 24, 2002



FDC Act

◆ 402(a)(3)

- "...consists in whole or in part of any filthy, putrid, or decomposed substance or is otherwise unfit for food..."

◆ 402(a)(4)

- "...prepared packed or held under insanitary conditions whereby it may have become contaminated with filth, or whereby it may have been rendered injurious to health..."

GMP 110.40(a)

Equipment and Utencils

- ◆ "...design construction, and use of equipment and utencils shall preclude the adulteration of food with lubricants, fuel, *metal fragments*, contaminated water, or any *other contaminants*..."

GMP 110.80(b)(8)

Manufacturing Operations

- ◆ “...Effective measures shall be taken to protect against the inclusion of *metal or other extraneous materials* in food. Compliance with this requirement may be accomplished by using sieves, traps, magnets, electronic metal detectors, or other suitable effective means...”

Controls Necessary

- ◆ Required to control 'adulteration'
- ◆ Specifically included in 'HACCP'-
physical hazards
 - Prerequisite Programs
 - CCP (?)
- ◆ Allow judgement of system integrity
- ◆ Prevent customer complaints

Control Program

- ◆ Incoming ingredients/raw materials
- ◆ Equipment protection
- ◆ After equipment which may fail or cause foreign materials
- ◆ End of system (e.g. packing, load out points)

Ingredients/Raw Materials

- ◆ Preventive approach
- ◆ Supplier performance measure
- ◆ GMP 110.80(a)(4), other regulations
- ◆ Down time and associated costs

Equipment Protection

- ◆ Protect expensive, sensitive equipment
- ◆ Examples: cutters, grinders, extruders, pumps, etc.
- ◆ After equipment which may generate-
 - cutter blades
 - mechanical wear points
- ◆ Maintenance/cleaning activity
- ◆ Break system into measurable parts

End of Systems

- ◆ Verification of overall program effectiveness
- ◆ 'Proof' of compliance- regulatory implications
- ◆ Protection against customer issues

Detection/Control Devices

◆ Magnets

◆ Screens/Scalping/Sifting

◆ Metal Detectors

◆ X-Ray Devices

Magnets

- ◆ Used to remove fine metals, not horseshoes
- ◆ May require several passes to retain 'paramagnetic' materials
- ◆ To protect equipment, particularly in explosive atmospheres

Magnet Function

- ◆ Attraction proportionate to size
- ◆ Strength varies by inverse square of distance from surface
- ◆ Field cannot be insulated
- ◆ Can be demagnetized by abuse:
extremes of heat, proximity of opposing fields, disassembly, etc.

Magnet Types

◆ Plates

- for chutes or spouts, can be suspended
- barrier or taper steps catch small contaminants

◆ Humps

- two or more plates in series
- for use on free-flow materials
- can catch hard to collect pieces
- can be used in gravity or pneumatic spouting with proper housing

Magnet Types

◆ Bar

- designed for fine contaminants in shallow product streams
- product must be free-flowing

◆ Grate

- for fine and small contaminants
- materials washed to underside of bar stream
- must be free flowing (no choke feed)
- metal must be in contact with bars

Magnet Types

◆ Liquid traps

- group of round bars vertically installed in pipe fitting
- contaminants washed to downstream side of bars
- viscosity of material in stream affects results- may need series of traps
- available in sanitary versions
- plate liquid trap also available with fitted baffle to direct stream down onto magnet surface

Magnet Selection

- ◆ Must consider types of expected contaminants
- ◆ Must be sized to capacity of site
- ◆ Flow characteristics must be considered
- ◆ Fabrication and construction are important
- ◆ Prior planning required to select strength, assure access

Magnet Checks

◆ Access to magnet is Critical!

- Up to the magnet
- Into the magnet
- At floor or platform level if at all possible

◆ Best: ability to check during operational conditions

Magnet Checks

- ◆ Heavily contaminated magnets lose separation ability-
 - pulling and holding power decreased
- ◆ Expect complete cleaning and removal of any metallic materials
 - supplier performance implications
 - timing for decision making
- ◆ Understand product flow, accumulations

Magnet Program

- ◆ Determine frequency of checks
- ◆ Describe documentation of checks and findings
- ◆ Collect and evaluate ANY findings
- ◆ Documentation of evaluations and follow-up actions

Scalping/Sifting

- ◆ Sieves and screens to detect/remove materials of differing size
- ◆ May be used to detect oversized or undersized materials
- ◆ Capability dependent on differences in particle size
- ◆ Effective on dry and liquid systems

Screening/Scalping

- ◆ Requires prior planning
- ◆ Must be matched to system
 - purpose intended
 - location in the system
 - screen size and type
 - ◆ nylon
 - ◆ wire
 - ◆ plate

Screening/Scalping

- ◆ Throughputs must be taken into account
 - open area of screen
 - available footprint
- ◆ Particle sizes define separation capabilities
 - bulk density is key

Screen/Scalp Types

◆ Flow-through screens

- pump liquids through screen traps
- round hole, slots, wire sieve

◆ Vibratory

- screen placed in product conveying bed
- depth of bed and particle size affect tailings quality

Screen/Scalp Types

◆ Sweco

- circular vibration for reduced footprint
- vigorous screen movement can increase separation rates
- may damage products

◆ Box sifter

- gentle motion over screen surface
- usually for fine particles
- allows greater cloth surface

Screen/Scalp Types

◆ Turbo sifters

- high speed rotary device within round horizontal screen assembly
- rotary paddles throw material against the screen surface
- may actually break-up foreign objects

◆ Many not considered effective as product protection devices!

Sensitivity Factors

- environmental conditions
- product moisture
- salinity/pH
- temperature
- operating speed
- throughput rate
- variation in product size
- type of metal
- shape of metal
- orientation of metal
- aperture dimensions
- position of metal in aperture

Ball Size and Wire Size

Spherical Sensitivity (Fe Ball)	Steel Paper Clip Dia 0.95mm (0.037")	Tinned Copper Wire Dia 0.91mm (0.036")	Copper Wire Dia 1.37mm (0.054")	Stainless Steel EN58E Dia 1.60mm (0.063")
● 1.2 mm	- 1.5 mm long (0.06")	- 3.5 mm long (0.14")		
● 1.5 mm	- 3.0 mm long (0.12")	— 9.0 mm long (0.36")	- 3.0 mm long (0.12")	— 8.0 mm long (0.31")
● 2.0 mm	— 6.0 mm long (0.24")	———— 26.0 mm long (1.02")	— 8.0 mm long (0.31")	———— 24.0 mm long (0.96")
● 2.5 mm	— 11.0 mm long (0.44")	————— 55.0 mm long (2.17")	— 18.0 mm long (0.72")	————— 64.0 mm long (2.52")

Each Item Drawn to Scale

Ball Size and Wire Size

Safeline PowerPhase Metal Detector

at 0° Phase

Ferrous Ball Size Sensitivity	Length of 2.3mm SS Wire Worst Orientation	Length of 2.3mm SS Wire Best Orientation
2.5mm	16 mm	8 mm
3.0 mm	34 mm	17 mm
3.5 mm	74 mm	37 mm
4.0 mm	- *	65 mm
4.5 mm	- *	95 mm

Low Frequency Operation

* - When wire length becomes longer than Metal Detector Coil Pitch it will no longer be detectable in this orientation

Size of Swarf v.s. Fe Ball Sensitivity

2.5mm Ø



S/S 316L



3.0mm Ø



S/S 316L



4.0mm Ø



S/S 316L



